

# How To:

## Install 1/2" Poly Fittings



**Tip:** Rub a small amount of cooking oil on the inside of the 1/2" Poly for even easier installation.



Pull the collar back to expose the barb with built-in O-ring.



Push the 1/2" Poly securely onto the barb and past the built-in O-ring.



Hand tighten the collar back over the 1/2" Poly.